

Ultrastab Saturn Current Transducer User Manual



Manufactured by:

Danfysik A/S
Mollehaven 31
DK 4040 Jyllinge
Denmark
Tel: +45 46 76 81 50 Fax: 45 46 73 15 51
Email: danfysik@danfysik.dk

Distributed by:

GMW Associates
955 Industrial Road
San Carlos, CA 94070, USA
Tel: (650) 802-8292 Fax: (650) 802-8298
Email: sales@gmw.com
Website: <http://www.gmw.com>

Table of contents:

1	Safety	5
1.1	Usage precautions and recommendations	5
1.2	Terms and symbols	5
1.3	Use and wear	5
1.4	AC Power input	5
1.5	Grounding	6
1.6	Fuses	6
2	Warranty	7
3	Receiving and unpacking	8
3.1	Receiving the Goods	8
3.2	Instructions for unpacking	8
4	Quick start	10
4.1	System overview	10
4.2	Power up	10
5	Introduction	12
5.1	Main Features	12
5.2	Front	12
5.3	Rear	13
5.4	Transducer heads	14
6	Installation	15
6.1	Mounting requirements	15
6.2	Mounting requirements for the transducer heads	15
6.3	Installation	16
6.4	Grounding the transducer heads	16
7	Jumpers	17
7.1	Jumper settings	17
8	Offset adjust	20
8.1	Adjusting the current offset	20
9.	IO-ports	22
9.1	Analogue out connector	22
9.2	Status/Interlock connector	22
9.3	Transducer head A connector	23
9.4	Transducer head B connector	24
9.5	Sync In and Sync out	24
10.	Operating instructions	26
10.1	Switching on power	26
10.2	Using the <i>ULTRASTAB SATURN</i> in current mode	26
10.3	Connecting directly to a current measuring device	26
10.4	Connecting to an external burden resistor	27
10.5	Using the <i>ULTRASTAB SATURN</i> in voltage mode (VOM installed)	27
10.6	Connecting the <i>ULTRASTAB SATURN</i> to a DMM or high impedance amplifier	27
10.7	Connecting the <i>ULTRASTAB SATURN</i> to a low resistance load.	28
10.8	Using the <i>ULTRASTAB SATURN</i> in a multichannel system.	28
11	Theory of operation	30
11.1	Basic principle of ULTRASTAB current transducers	30

12	Maintenance	32
13	Parts and accessories	33
	Appendix A: Sales representatives	35
	Appendix B: Specifications	
	Appendix C: Drawings	

FCC statement:

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference in which case the user will be required to correct the interference at his own expense.





1 Safety

1.1 Usage precautions and recommendations

The following precautions are recommended to insure your safety and to provide the best conditions of this instrument. If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

1.2 Terms and symbols

These terms and symbols may appear in this manual or on the product.

	WARNING: Warning statements identify condition or practices that could result in injury or loss of life.
	CAUTION: Caution statement identify conditions or practices that could result in damage to the product.
	DANGER: High Voltages.
	Protective Conductor Terminal.

1.3 Use and wear



Caution

Do not place any heavy object on the instrument.
 Avoid severe impacts or rough handling that could damage the instrument.
 Use electrostatic discharge precautions while handling and making connections to the instrument.
 Do not place wires into the connectors of the instrument, only mating connectors and adapters.
 Do not block or obstruct the ventilation opening on the side panels and over the heat sink.

1.4 AC Power input



Caution

AC power input should be within the range of the selected line voltages +/-10%.

1.5 Grounding



WARNING:

To avoid electrical shock the power cord protective grounding conductor must be connected to earth ground.

All transducerheads must be connected to earth ground as described in chapter 5.4.

Failure to establish a functional ground connection to earth may cause malfunction and lead to hazardous errors.

1.6 Fuses



WARNING:

The unit is delivered with two T1A fuses. For continued fire protection replace the fuses with the specified type and rating only.

To replace the fuses disconnect the mains cord. Open the cover of the IEC power inlet with a flat screwdriver. Pull out the fuse holders and replace the fuses.

2 Warranty

DANFYSIK A/S warrants the equipment delivered from the company to be free from any defects in materials and workmanship for a period of:

12 Months from the date of installation or max. 18 months from the date of shipment, whichever is shortest.

Within this warranty period DANFYSIK A/S will repair or replace any defective parts free of charge either on the customer's site or at our factory at our choice.

DANFYSIK A/S will pay or reimburse the lowest two way freight charges on any items returned to DANFYSIK A/S or our designated agent-/representative provided prior written authorization for such return has been given by DANFYSIK A/S.

This warranty shall not apply to any equipment which our inspection shows to our satisfaction, to have become defective or unworkable due to mishandling, improper maintenance, incorrect use, or any other circumstances, not generally acceptable for equipment of a similar type.

DANFYSIK A/S reserves the right on standard products to make changes in design without incurring any obligation to modify previously manufactured units.

The foregoing is the full extent of the warranty and no other warranty is expressed or implied. If no event Danfysik shall be liable for special damage arising from the delivery, late delivery, or use of the equipment.

If any fault develops the following steps should be taken:

Notify DANFYSIK A/S giving full details of the problems and include Model, Type, Serial number, and Order number.

On receipt of this information DANFYSIK A/S will send you either service information or instructions for shipping.

All shipments of DANFYSIK A/S equipment should be made according to our instructions and shipped in the original or a similar package. For smaller parts a cardboard carton will be sufficient, providing the parts are wrapped in plastic or paper and surrounded with at least 10 centimetres of shock-absorbing material.

3 Receiving and unpacking

3.1 Receiving the Goods

The shipping package and the *ULTRASTAB SATURN* should be thoroughly inspected for signs of obvious damage immediately upon receipt. All materials in the package should be checked against the enclosed packing list and the list of standard delivery below. DANFYSIK A/S will not be responsible for any shortages unless notified immediately.

ULTRASTAB SATURN Standard Delivery:

- 1 x Saturn Electronics
- 1 x **Saturn Transducer Head** (STH)
- 1 x Programming plug*
- 1 x Connection cable with plugs from the Saturn to the transducer head**
- 1 x Analogue out cable***
- AC power cord
- Manual
- Certificate of calibration (Only when delivered with a Voltage output!)

* If rating was not specified when ordering following programming plug will be delivered:

- 600 A type: 1 x 600 A
- 2000 A type: 1 x 2000 A
- 5000 A types: 1 x 5000 A

** Unless specified when ordering the following transducer head connection cable will be delivered:

- Current output: 10m connection cable with either DSUB plugs (Part no. 65894070) for 600A systems or Amphenol plugs (Part no. 65894110) for 2000/5000A systems.
- Voltage output: 2.5m connection cable with either DSUB plugs (Part no. 65892220) for 600A systems or Amphenol plugs (Part no. 65892210) for 2000/5000A systems.

*** Unless specified when ordering the following analogue output cable will be delivered:

- Current output: Current adaptor cable (part no. 65894180) DSUB to 4mm safety banana sockets. See chapter 10.
- Voltage output: Analogue output cable with standard sense (part no. 65893820). See chapter 10.

3.2 Instructions for unpacking

The *ULTRASTAB SATURN* is shipped in a cardboard carton.

If the equipment is damaged in any way a claim should be filed with the shipping agent, and a full report of the damage should be forwarded to Danfysik A/S or our local agent/representative immediately.

Upon receipt of this report you will be issued instructions for the repair, replacement, or return shipment.

Please include the Model No., Type No., Serial No. and Order No. for the *ULTRASTAB SATURN* on any communication with DANFYSIK A/S or our representative.

4 Quick start

4.1 System overview




Figure 1

4.2 Power up

To quickly get your new *ULTRASTAB SATURN* up and running follow the following instructions.

A: Connect the transducer head to the unit using the supplied transducer head cable and mount the programming plug in the connector on the head.

B: Connect a DMM to the unit in one of two ways.

1: If your unit has a voltage output:

Connect the analogue output cable (DF. No.: 65893820) to the analogue out port. Connect the red wire of the cable to the positive terminal on the DMM and the black wire to the common

terminal. Set the DMM to measure DC voltage in a range greater than $\pm 10V$.

2: If your unit has a current output:

Connect the current output adaptor (DF. No. 65894180) to the analogue out port. Use a wire with 4mm terminal male plugs to connect the red wire on the adaptor to the current input terminal on the DMM. Use a similar wire to connect the black wire of the adaptor to the common terminal on the DMM. Set the DMM to measure DC current in a range greater than $\pm 1A$ (or $\pm 2A$ if you bought a 5000A system).

C: Make sure the voltage selector on the IEC inlet is set to the local voltage and connect the power cord.

D: The *ULTRASTAB SATURN* will now measure the current running through the transducer head. On the front plate the status of the unit can be monitored using the 7 LED's.

5 Introduction

5.1 Main Features

The *ULTRASTAB SATURN* is a high precision current measuring device based on the Flux-gate principle. It can measure current in both the DC and AC domain. The instrument can be configured in a variety of ways to suit the user's demands. Amongst the Ultrastab's main features are:

- Current or voltages output
- Programmable current range from 0 – 5000A
- Status signals for interfacing with other equipment
- Synchronization option in multichannel setup

The *ULTRASTAB SATURN* can be used either with or without an internally mounted **V**oltage **O**utput **M**odule (VOM). With a VOM installed the unit will produce a signal of $\pm 10V$. Without the VOM installed a signal of $\pm 1A$ or $\pm 2A$ depending on the transducer head will be produced.

The current to be measured can be between 0 – 5000A depending on the transducer head. A selection of 4 different transducer heads is available.

- 600A transducer head programmable in steps of 20A
- 2000A transducer head programmable in steps of 125A
- 5000A transducer head programmable in steps of 250A
- 5000A transducer head with wide body hole programmable in steps of 250A

To program the current range of the transducer head a programming plug is used. This plug sets the ratio between the current measured and the output signal of the *ULTRASTAB SATURN*.

E.g.: A 600A transducer head programmed with a 300A programming plug will produce an output signal of 10V (or 1A) when the current through the head is 300A.

5.2 Front




Figure 2

On the front of the *ULTRASTAB SATURN* there are 7 LED's for indication of system status, warning and error.

POWER: This LED is lit (Blue) when the *ULTRASTAB SATURN* is on.

STATUS: This LED is lit (Green) when the status of the unit is OK.

I_p LOW: This LED is lit (Yellow) when the current passing through the transducer head is below 5‰ of the programmed maximum current.

600A: This LED is lit (yellow) when a 600A transducer head is connected to the *ULTRASTAB SATURN*.

2000A: This LED is lit (yellow) when a 2000A transducer head is connected to the *ULTRASTAB SATURN*.

5000A: This LED is lit (yellow) when a 5000A transducer head is connected to the *ULTRASTAB SATURN*.

OVERLOAD: This LED is lit (red) when the current passing through the transducer head exceeds 130% of the maximum current for the transducer head (including programming) or the transducer head saturates.

5.3 Rear




Figure 3

All connectors on the *ULTRASTAB SATURN* are placed on the rear of the unit.

- 1: IEC power inlet and voltage selector. This connector accepts a standard IEC power cord (supplied). The voltages can be changed using the voltages selector code wheel in order to match local voltages. Furthermore, the unit's two mains fuses are located in the IEC power inlet. To change the fuses see 1.5.
- 2: Punch out plate. This plate is for future expansion or customization
- 3: Type / Serial number plate
- 4: Sync in. Synchronization input when slaved to another *ULTRASTAB SATURN* in a multichannel system.
- 5: Sync out. Synchronization out when the unit is master or part of a daisy-chain in a multichannel system.
- 6: Status/Interlock signals output.
- 7: Transducer head A: Connection to the STH600 head using cable 89222.
- 8: Transducer head B: Connection to the 2000A and 5000A head using cable 89221.
- 9: Analogue out. Port for connection to a DMM or other equipment.

- 10: Calibration date label (on units with VOM installed)
- 11: Serial no. plate of matched transducerhead. This plate is only mounted if a transducerhead is delivered with the electronics unit.

5.4 Transducer heads

All transducer heads contain 2 connectors. A connector for connecting the transducer head with the transducer head cable and a connector for the programming plug.

The programming plug connector is a DSUB 25 Male connector on all transducer heads while the connector for the transducer head cable is a DSUB15 Male connector on the STH600 head and a Amphenol C16-3 Female connector on the STH2000, STH5000-62 and STH5000-140.




Figure 4

6 Installation

6.1 Mounting requirements

The *ULTRASTAB SATURN* can be mounted in either a rack based system or as a stand alone unit using the supplied rubber feet.



Warning:

The unit must be mounted horizontally. To ensure proper cooling the heat sink on the right and the air inlet on the left side of the unit must be kept free. Failure to do this may result in improper cooling of the system which may lead to malfunction of the unit.

6.2 Mounting requirements for the transducer heads

STH 600: Use the mounting bracket no.: 88262 to mount the 600A transducer head. It may be installed in any direction.

STH 2000: The 2000A transducer head must be installed using two M8 screws. The head may be mounted in any direction. Please observe that the length of the screws may not exceed the length D shown in figure 5. To calculate the maximum length of the mounting screw, measure the thickness of the mounting substrate C and add the length A + B which is 10mm + 15mm.

Max. Screw length:
 $D = 10 + 15 + C$ [mm]




Figure 5

**WARNING:**

Using too long screws may cause harm to the inner parts of the transducer head and lead to malfunction.

STH 5000A-62 and **STH 5000-140** transducer heads are mounted using four M10 screws inserted into the holes on the brackets. The heads can be installed in any directions.

6.3 Installation

1. Check that the mains voltage and frequency matches to the local requirements. If not, the proper voltage on the selector wheel, 100, 115, 230 Volt AC must be selected to match the line voltage.
2. Establish the Ground connection according to the local authority regulations and the requirements of the equipment.
3. Mount the provided connection cable between the *ULTRASTAB SATURN* and the transducer head. Please note that only one transducer head may be connected to either transducer head A or transducer head B plug.
4. Connect the analogue output terminals as described in the next chapter
5. Check that all cables terminated in a plug are pushed fully home.
6. Connect the supplied power cord to the IEC inlet on the unit to turn it on.

The transducer head and electronics can be installed up to 30 metre cable distance from each other. The transducer head may be installed in any orientation.

6.4 Grounding the transducer heads

For safety reasons the transducer heads must be connected to earth. To connect a transducer head to earth follow these steps:

STH 600: Connect an earth wire to the earth connector on the front plate of the transducer head.

STH 2000: Connect the earth wire to the transducer head using a M8 ringtounge fastened to one of the 4 mounting holes with a M8 screw.

STH 5000-62 & STH 5000-140: Connect the earth wire to the transducer head using a M10 ringtounge fastened to one of the 4 mounting holes on the brackets.

7 Jumpers

7.1 Jumper settings

The *ULTRASTAB SATURN* contains a number of jumpers which are used to configure the unit.

The default factory setting should in most cases be the preferred configuration. However, it may be necessary to alter the settings to match the unit to your application.

To change the jumper setting first make sure the unit is powered off and the power cord is detached. Then remove the top cover using a screw-driver. Locate the jumper you need to change and change the setting.

In a standard *ULTRASTAB SATURN* there are 5 jumpers. 3 on the Transducer Electronic Module (TEM) and 2 on the MotherBoard (MB).

Additionally there are 2 jumpers more in a unit with a VOM installed. The locations of the jumpers are shown below.







Figure 6

MB Jumper 1: Current / Voltage out

Located to the left on the motherboard. This is a 3 by 2 pin jumper and is used to choose between current output (no VOM installed) or voltage output (VOM installed).

Default setting: 1 in current out mode

Default setting: 3 in voltage out mode

	1	2	3
Configuration			
Function	Current output	VOM installed	VOM installed. Reversed phase

MB Jumper 2: Chassis/GND

Located at the left on the motherboard just above jumper 1. This is a 2 pin jumper and is used to connect or disconnect the chassis of the unit with it's internal GND plane. With a jumper mounted Chassis and GND is shorted.

Default setting: Shorted

MB Jumper 3: Sweep test




Located at the rightmost corner of the motherboard. This is a 4 pin jumper and is used to test the sweep function. This is done by shorting pin 3 and 4. The sweep signal can then be monitored on pin 1 and 2.

Default setting: Open

TEM Jumper 1: Sync source selector

Located to the left on the TEM. This is a 4 pin jumper and is used to define whether the unit's clock source is taken from its own internal clock, or from the SYNC IN connector on the rear of the unit.

Default setting: 2

	1	2	3
Configuration			
Function	No clock source	Internal clock (Master) <u>Default setting</u>	External clock (Slave)




TEM Jumper 2: Power amp on

Located to the right on the TEM behind the 9 pole weidmüller connector (ORANGE). This is a 2 pin jumper. This jumper must always be shorted on the *ULTRASTAB SATURN*.

Default setting: Shorted

TEM Jumper 3: Saturation fault mode selector

Located to the right on TEM. This 3 pin jumper is used to select which action the *ULTRASTAB SATURN* must take if the transducer head is saturated. In mode 2 the unit will automatically begin to sweep in order to lock on to the current again. In mode 3 the *ULTRASTAB SATURN* will shut down the measuring circuit and wait until the current through the transducer head is near zero. Then the measuring will begin again. This mode is useful in systems where the *ULTRASTAB SATURN* is part of a feedback line.

	1	2	3
Configuration			
Function	Not used	Sweep mode <u>Default setting</u>	Measuring disable mode

Default setting: 2

VOM Jumper 1: High

Located behind the 4 pole wiedmüller connector (ORANGE) on the VOM. This is a 2 pin jumper. When shorted the signals high sense and high out is shorted.

Default setting: Open

VOM Jumper 2: Low

Located behind the 4 pole wiedmüller connector (ORANGE) on the VOM. This is a 2 pin jumper. When shorted the signals low sense and low out is shorted.

Default setting: Open

8 Offset adjust

The *ULTRASTAB SATURN* should occasionally have a current offset adjustment made to ensure the highest accuracy.

All *ULTRASTAB SATURN*'s are offset adjusted by DANFYSIK with the ordered transducer head prior to shipment. In case the *ULTRASTAB SATURN* has been recalibrated or serviced, and minimum after ½ years of operation, it is advisable to perform an offset adjustment with the selected transducer head connected prior to any measurement in order to achieve the highest accuracy.

8.1 Adjusting the current offset



WARNING



CAUTION

During offset adjustment the unit needs to be powered up with the top lid removed. This will potentially exposing the operator to high voltages. As a consequence the operator is requested not to touch anything inside the unit.

Note:

If the unit is equipped with a VOM be sure not to adjust any of the potentiometers on the VOM as this will cancel the calibration of the VOM, and the unit will need a new calibration.

To adjust the *ULTRASTAB SATURN* please follow these steps.

1. Unplug the mains cord
2. Remove the screws holding the cover and remove it.
3. Connect a DMM capable of measuring μA to the analog output port using a current output cable (no.:89418) see chapter 10.3.
4. Connect the mains cord to the IEC inlet.
5. Wait for approx. 15 minutes while the unit is heating up.
6. Locate the offset adjustment potentiometer on the TEM (see fig. 7)
7. Use a trim screwdriver to adjust the offset until the current is as close to zero as possible.
8. After adjustment unplug the mains cord and mount the cover again.




Figure 7

9. IO-ports

9.1 Analogue out connector

The Analogue out connector (DSUB15 Female) contains the following signals:

1: Current return	2: Current return	3: Not used	4: Vo High Sense	5: Vo High Out	6: Ground	7: Vo Low Sense	8: Vo Low Out
9: Current out	10: Current out	11: Not used	12: Vo High Sense	13: Vo High Out	14: Vo Low Sense	15: Vo Low Out	

When using the *ULTRASTAB SATURN* in current out mode (no VOM installed) only pin 1, 2, 9, 10 should be used.

Pin 9, 10: Is the current output from the *ULTRASTAB SATURN*.

Pin 1, 2: Current return path.

When using the *ULTRASTAB SATURN* in voltage out mode (VOM installed) pin 1 - 9 and pin 2 - 10 must be shorted. This will loop the current output to the VOM.

The voltage output is then present on pin 4 - 8 and 12 - 15.

Pin 4, Pin 12: Voltage output High sense

Pin 6: Signal Ground

Pin 7, Pin 14: Voltage output Low Sense

Pin 8, Pin 15: Voltage output Low

Pin 5, Pin13: Voltage output high

9.2 Status/Interlock connector

All signals on the Status/Interlock port are floating relay type. All signals are therefore isolated from the electrical circuits of the unit.



WARNING:

Maximum allowed voltage on the relay switches is 33VAC or 70VDC. Exceeding this limit may cause malfunction or damage the equipment.

The Status/Interlock connector (DSUB9 Male) contains the following signals:

1: Normal operation on	2: Normal operation off	3: Ip Low common	4: Overload warning on	5: Overload warning off	Pin 1:
6: Normal operation common	7: Ip Low on	8: Ip low off	9: Overload warning common		

Normal operation on. When the unit status is OK (Normal operation) this pin is connected to the Normal operation common pin.

Pin 2: Normal operation off. When the unit status is not OK (error, overload warning etc.) this pin is connected to the Normal operation common.

Pin 3: Ip Low common: This pin is connected to either Ip Low on or Ip Low off depending on the unit's status.

Pin 4: Overload warning on: This pin is connected to the Overload common pin when the current through the transducer head exceeds 10% of the maximum programmed current.

Pin 5: Overload warning Off: This pin is connected to the Overload common pin when the unit is in normal mode and the current through the transducer head is within the measurement area.

Pin 6: Normal operation common: This pin is connected to either Normal operation on or the Normal operation off depending on the unit's status.

Pin 7: Ip Low on: This pin is connected to Ip Low common when the current through the transducer head is below 5‰ of the programmed current.

Pin 8: Ip Low off: This pin is connected to the Ip Low common when the current through the transducer head is above 5‰ of the programmed current.

Pin 9: Overload warning common: This pin is connected to either Overload warning on or Overload warning off pin depending on the unit's status.

9.3 Transducer head A connector

The transducer head A connector is used to connect the STH 600 transducer head (DF part no: 89254) to the *ULTRASTAB SATURN*. The connection is made using the transducer head cable type A (DF part no. 89222). This is a 2.5M long non-halogen cable with a DSUB15 Male connector in each end.

1:ICR	2:ICO	3:NC	4:FB-	5:IDEN-	6:NC	7:ZD1-	8:ZD1+
9:ICR	10:ICO	11:FB+	12:NC	13:IDEN+	14:ZD2-	15:ZD2+	

Pin 1: Compensation current return

Pin 2: Compensation current out

Pin 3: No connection

Pin 4: Feedback coil – (AC pickup)

Pin 5: Identification -

Pin 6: No connection

Pin 7: Zero detector coil 1 –

Pin 8: Zero detector coil 1 +

Pin 9: Compensation current return

Pin 10: Compensation current out

Pin 11: Feedback coil + (AC pickup)

Pin 12: No connection

Pin 13: Identification +

Pin 14: Zero detector coil 2 –

Pin 15: Zero detector coil 2 +

9.4 Transducer head B connector

The transducer head B connector is used to connect the STH 2000, STH 5000-62 or STH 5000-140 transducer head (DF part no: 89247, 89248, 89249) to the *ULTRASTAB SATURN*. The connection is made using the transducer head cable type B (DF part no. 89222). This is a 2.5M long non halogen cable with an Amphenol C16-3 Male connector in each end.

Pin Earth: Chassis

Pin 1: No connection

Pin 2: Compensation current out

Pin 3: Compensation current return

Pin 4: Identification -

Pin 5: Identification +

Pin 6: Zero detector coil 1 +

Pin 7: Zero detector coil 2 +

Pin 8: No connection

Pin 9: Zero detector coil 1 -

Pin 10: Zero detector coil 2 -

Pin 11: No connection

Pin 12: Feedback coil + (AC pickup)

Pin 13: Feedback coil - (AC pickup)

Pin 14: No connection




Figure 8

9.5 Sync In and Sync out

The Sync In connector is used to input and external synchronization signal from another *ULTRASTAB SATURN*.

The Sync out connector is used to send out a synchronization signal to another *ULTRASTAB SATURN*.

An optocoupler in the Sync In circuitry secures that no galvanic connection exists between the sync master and the sync slave.

Both connectors are standard 8 ways modular jack connector (RJ45), and accepts standard network patch cables. Cables may be straight or cross-over cables as the *ULTRASTAB SATURN* only uses those wires in the cable that is always straight (connection 4 and 5).

The Sync signal is present on Pin 4 while Pin 5 is ground (0V)




Figure 9

10. Operating instructions

10.1 Switching on power



Warning:

Before switching on the power make sure that there is no current running through the transducer head.

Note:

The disconnecting device on this equipment is the **mains plug**. To disconnect the unit unplug the mains plug at the power inlet.

Before powering up the *ULTRASTAB SATURN* make sure all jumper settings are correct and that all connections are pushed fully home and secured properly. Check that the voltage selector is set to match the local voltage supply and that the earth connection is correct according to local law and regulation. When everything is connected according to above; plug in the power cord connector. The *ULTRASTAB SATURN* will now run through its power up sequence. After a few second the unit is ready and the status of the unit can be seen on the front panel LED's. The power, status, I_pLOW and one of the transducer head LED's should now light up. Now switch the current through the transducer head on. The I_pLOW LED should turn off and the unit is running.

10.2 Using the *ULTRASTAB SATURN* in current mode

When using the *ULTRASTAB SATURN* without a VOM installed there are essentially two ways to measure the output. Connecting it to a DMM, or connecting it to an external burden resistor.

In either way the user must observe that the maximum burden resistance does not exceed the value given in the specifications of the unit.

10.3 Connecting directly to a current measuring device

Connecting the *ULTRASTAB SATURN* directly to a current measuring device like a DMM or an Power analyzer, can easily be done using the Current output adaptor (no.: 89418) which is supplied with all delivered *ULTRASTAB SATURN* systems without a VOM installed. The adaptor accepts male 4mm banana plugs. The red wire carries the output current while the black is the current return path. Simply connect these two wires to your current measuring device using standard laboratory test leads with 4mm terminals (see figure 10).




Figure 10

10.4 Connecting to an external burden resistor

If an external burden resistor is to be connected to the *ULTRASTAB SATURN* the following diagram should be used. This diagram is equal to the *ULTRASTAB SATURN* output cable type C (no.:89387)




Figure 11

10.5 Using the *ULTRASTAB SATURN* in voltage mode (VOM installed)

When a VOM is installed there are two ways to connect the *ULTRASTAB SATURN* to an external load.

10.6 Connecting the *ULTRASTAB SATURN* to a DMM or high impedance amplifier

When connecting the *ULTRASTAB SATURN* to a DMM or high impedance load in voltage mode the following connections must be used. This diagram is equal to the standard voltage output cable. *ULTRASTAB SATURN* output cable type B (no.: 89382).




Figure 12

10.7 Connecting the *ULTRASTAB SATURN* to a low resistance load.

When connecting the *ULTRASTAB SATURN* to a low resistance load in voltages mode the following connections must be used. This diagram is equal to the *ULTRASTAB SATURN* output cable type A (no.: 89374). Please note that this setup will have a small negative impact on the precision of the *ULTRASTAB SATURN* due to the resistance in the sense wires which will alter the feedback resistance slightly in the output amplification circuitry.




Figure 13

10.8 Using the *ULTRASTAB SATURN* in a multichannel system.

To use the *ULTRASTAB SATURN* in a multichannel system the first unit can be configured as synchronization master (see jumper settings) and the following units as synchronization slave. This insures that all units are working with the same clock which will limit noise and interference. It is however, not mandatory to use the synchronization, for many applications it is not necessary due to the low noise floor of the system.

Below is shown a 3 channel system.




Figure 14

11 Theory of operation

11.1 Basic principle of ULTRASTAB current transducers

The ULTRASTAB current transducers is delivered in a programme covering a potential free measurements of currents from DC to 500 kHz ranging from 40 A to 25 kA.

The precision current transducers are using a zero flux principle controlling a compensation current which counterbalance the ampere turns generated of the primary current. Due to a balanced zero detector principle the output noise level is by nature very low and a resolution in the order of 2×10^{-8} is achieved.

The figure below shows a block diagram of the zero flux transducer principle.




Figure 15

The transducer head core (1) is the basic body structure. The cores (2) and (3) are flux detector cores coupled to the electronics zero flux detector circuitry by means of the coils L1 and L2.

L1 and L2 are coupled in parallel or serial, depending of model, with opposite phase to reduce the unwanted flux generated in core 1.

With a primary current I_p flowing through L4 a magnetic flux will be generated in the body structure and detected by the detector cores. An error signal will be generated, controlling the amplifier A1 to drive a current through the compensation winding L3. When counterbalance is obtained, i.e. zero flux is reestablished, the compensation current, multiplied with the number of turns in L3, is a true expression of the primary current I_p .

The zero flux detector circuitry operates from true DC to about 1Hz. For higher frequencies the "AC pick up winding" L5 performs a feed back error signal which via the amplifier A2 widens the active bandwidth of the transducer up to more than 10 kHz.

Above 10 KHz the DCCT operates as a passive current transformer with it's -3dB limit variation from 300 KHz to 1 MHz depending on size and construction of the DCCT.

12 Maintenance

The *ULTRASTAB SATURN* does not require any maintenance under normal operation in the version with a current output.

ULTRASTAB SATURN with voltage output requires yearly or biyearly calibration. Calibration of the unit is done according to the *Ultrastab Saturn* Calibration manual, document no. 88600010.

If the unit needs service please contact Danfysik A/S or our local sales representative.

13 Parts and accessories

81089200	<i>ULTRASTAB SATURN</i> electronic unit
81089254	STH 600, 600A transducer head
81089247	STH 2000, 2000A transducer head
81089248	STH 5000-62, 5000A transducer head, 62mm centre hole
81089248	STH5000-140, 5000A transducer head, 140mm centre hole
81089395	1A VOM (For STH 600/STH 2000)
81089396	2A VOM (For STH 5000-62/ STH 5000-140)
81088262	STH 600 mounting bracket
65892220	Transducer head cable for STH 600, 2.5M
65894060	Transducer head cable for STH 600, 5M
65894070	Transducer head cable for STH 600, 10M
65894080	Transducer head cable for STH 600, 20M
65894090	Transducer head cable for STH 600, 30M
65892210	Transducer head cable for STH 2000, STH 5000-62, STH 5000-140, 2.5M
65894100	Transducer head cable for STH 2000, STH 5000-62, STH 5000-140, 5M
65894110	Transducer head cable for STH 2000, STH 5000-62, STH 5000-140, 10M
65894120	Transducer head cable for STH 2000, STH 5000-62, STH 5000-140, 20M
65894130	Transducer head cable for STH 2000, STH 5000-62, STH 5000-140, 30M
65893740	Output cable type A, 1.5M
65893820	Output cable type B, 1.5M
65893870	Output cable type C, 1.5M
65894180	Output cable DSUB to 4mm banana socketsl adaptor
81089259	40A/125A Programming plug for STH 600/ STH 2000
81089260	60A/250A Programming plug for STH 600/ STH 2000
81089261	80A/250A Programming plug for STH 600/ STH 2000
81089262	100A/375A Programming plug for STH 600/ STH 2000
81089263	120A/375A Programming plug for STH 600/ STH 2000
81089264	140A/500A Programming plug for STH 600/ STH 2000
81089265	160A/500A Programming plug for STH 600/ STH 2000
81089266	180A/625A Programming plug for STH 600/ STH 2000
81089267	200A/625A Programming plug for STH 600/ STH 2000
81089268	220A/750A Programming plug for STH 600/ STH 2000
81089269	240A/750A Programming plug for STH 600/ STH 2000
81089270	260A/875A Programming plug for STH 600/ STH 2000
81089271	280A/875A Programming plug for STH 600/ STH 2000
81089272	300A/1000A Programming plug for STH 600/ STH 2000
81089273	320A/1000A Programming plug for STH 600/ STH 2000
81089274	340A/1125A Programming plug for STH 600/ STH 2000
81089275	360A/1125A Programming plug for STH 600/ STH 2000
81089276	380A/1250A Programming plug for STH 600/ STH 2000

81089277	400A/1250A Programming plug for STH 600/ STH 2000
81089278	420A/1375A Programming plug for STH 600/ STH 2000
81089279	440A/1375A Programming plug for STH 600/ STH 2000
81089280	460A/1500A Programming plug for STH 600/ STH 2000
81089281	480A/1500A Programming plug for STH 600/ STH 2000
81089282	500A/1625A Programming plug for STH 600/ STH 2000
81089283	520A/1625A Programming plug for STH 600/ STH 2000
81089284	540A/1750A Programming plug for STH 600/ STH 2000
81089285	560A/1750A Programming plug for STH 600/ STH 2000
81089286	580A/1875A Programming plug for STH 600/ STH 2000
81089287	600A/1875A Programming plug for STH 600/ STH 2000
81089288	620A/2000A Programming plug for STH 600/ STH 2000
81089289	2500A Programming plug for STH 5000-62/ STH 5000-140
81089290	2750A Programming plug for STH 5000-62/ STH 5000-140
81089291	3000A Programming plug for STH 5000-62/ STH 5000-140
81089292	3250A Programming plug for STH 5000-62/ STH 5000-140
81089293	3500A Programming plug for STH 5000-62/ STH 5000-140
81089294	3750A Programming plug for STH 5000-62/ STH 5000-140
81089295	4000A Programming plug for STH 5000-62/ STH 5000-140
81089296	4250A Programming plug for STH 5000-62/ STH 5000-140
81089297	4500A Programming plug for STH 5000-62/ STH 5000-140
81089298	4750A Programming plug for STH 5000-62/ STH 5000-140
81089299	5000A Programming plug for STH 5000-62/ STH 5000-140

Appendix A: Sales representatives

DANFYSIK A/S,

Moellehaven 31,

DK-4040 Jyllinge

DENMARK

Phone No.: +45 46 79 00 00

Fax No.: +45 46 79 00 01

E-mail: sales@danfysik.dk

WWW.danfysik.dk

DISTRIBUTORS

EUROPE

Belgium

AllianTech S.A.S.

12, rue Traversière

92230 Gennevilliers

FRANCE

Phone No.: +33 1 47 90 77 77

Fax No.: +33 1 47 33 32 20

E-mail: information@alliantech.com

France

AllianTech S.A.S.

12, rue Traversière

92230 Gennevilliers

FRANCE

Phone No.: +33 1 47 90 77 77

Fax No.: +33 1 47 33 32 20

E-mail: information@alliantech.com

Germany

Signaltec GmbH

Dr. Carlo-Schmid-Straße 112

D-90491 Nürnberg

Phone No.: +49 (911) 5971 919

Fax No.: +49 (911) 5971 920

E-mail: info@signaltec.com

www.signaltec.com

Slovakia**LT IMPORT s.r.o.**

Letna 45

041 95 Kosice

SLOVAK REPUBLIC

Phone No.: +421 55 6331924

Fax No.: +421 55 6331924

E-mail: ltimport@kbc.sk**NORTH AMERICA****USA****GMW ASSOCIATES**

955 Industrial Road

San Carlos, CA 94070

Phone No.: +1 (650) 802-8292

Fax No.: +1 (650) 802-8298

E-mail: sales@gmw.comwww.gmw.com**ASIA****CHINA****Clover Technology Group, Inc.**

No 56A South Street, Zhong Guan Cun

Fang Yuan Mansion, Suite B 0201

Beijing 100044

CHINA

Phone No.: +86-10-88026823

Fax No.: +86-10-88026856

E-mail: gianlg@clovertex.com

INDIA**TRANSACT INDIA CORPORATION**

5/1A, Grants Building

Arthur Bunder Road

Colaba

Mumbai - 400 005

Phone No.: +91 (22) 563 64 866

Fax No.: +91 (22) 228 52 326

E-mail: trans@vsnl.com**JAPAN****TOYO DENGENKIKI CO., LTD.**

2306 Nippa-cho Kouhoku-ku

Yokohama-City

Kanagawa-pre

223-0057 JAPAN

Phone No.: +81-(0)45-543-1002

Fax No.: +81-(0)45-546-1479

E-mail: k.amemiya@toyodengenkiki.co.jp**Korea****Hanmac Corporation**

SK Bldg. 1001

16-4 Sungsu-1Ga, 2-Dong

Sungdong-Gu

Seoul

KOREA

Phone No.: +82-2-467-7447

Fax No.: +82-2-467-6816

E-mail: hanmac@hanmacco.comwww.hanmacco.com

Appendix B: Specification

Ultrastab Saturn 600I

Last update: 15.03.2007

Rack mounted programmable current transducer

Parameter	Symbol	Condition	Value	Unit
Primary current	I_p			
Nominal primary current			± 600	A
Programmable from			40	A
Programming steps			20	A
Polarity			Bipolar	
Secondary current	I_s			
Nominal secondary current			± 1	A
External burden resistor	R_b			
Max.	$R_{b, \max}$		1.5	Ω
Min.	$R_{b, \min}$		0	Ω
Current transfer ratio	N		600	
Overload capacity				
Max. nondestructive overload	$I_{p, \max}$	@ 0.1s	500	%I _{pn}
Min. overload trip value	$I_{p, \text{trip}}$		130	%I _{pn}
DC accuracy				
Offset				
Initial	I_{so}		< 2	ppm
Drift vs. Temp.	$I_{so, \text{temp}}$		< 0.1	ppm / K
Drift vs. Time	$I_{so, \text{time}}$		< 1	ppm / month
Transfer ratio				
Deviation	N_d		< 2	ppm
Deviation vs. Temp.	$N_{d, \text{temp}}$		< 0.1	ppm / K
Deviation vs. Time	$N_{d, \text{time}}$		< 1	ppm / month
Linearity				
Deviation	X_d		< 1	ppm
Deviation vs. Temp.	$X_{d, \text{temp}}$		< 0.1	ppm / K

Ultrastab Saturn 600I

Last update: 15.03.2007

Rack mounted programmable current transducer

Parameter	Symbol	Condition	Value	Unit
Output noise	$I_{s, \text{noise}}$			
		0 - 10Hz	< 0.01	ppm (RMS)
		0 - 10kHz	< 3.5	ppm (RMS)
		0 - 100kHz	< 6.5	ppm (RMS)
Dynamic response				
Slew rate	dI/dt	10 - 90%	> 50	A / μS
Delay time	t_d		< 1	μS
Bandwidth $\pm 3dB$	f	< 5% I_{pn}	0 - 300	kHz
Busbar noise Measured on primary cable, one turn	U_b	DC - 100kHz	< 2	μV RMS
Busbar free zone				
Lenght	l		150	mm
Radius	r		75	mm
Operating voltages Max. busbar voltages	$V_{b, \text{max}}$		1250	VAC
Test voltages Busbar to GND	$V_{t, b}$		5000	VAC RMS
Power supply				
Supply voltage (Selectable on mains inlet)	V_{ac}	$\pm 10\%$	100/110/230	VAC, 50~60Hz
Maximum power consumption	S_{max}		50	VA

Ultrastab Saturn 600I

Last update: 15.03.2007

Rack mounted programmable current transducer

Parameter	Symbol	Condition	Value	Unit
Operating environment				
Electronics				
Temperature	$T_{a, \text{elec.}}$		10 - 40	°C
Humidity	$RH_{a, \text{elec.}}$	Noncondensing	20 - 80	%RH
Transducerhead				
Temperature	$T_{a, \text{head}}$		0 - 55	°C
Humidity	$RH_{a, \text{head}}$	Noncondensing	20 - 80	%RH
Storage environment				
Electronics				
Temperature	$T_{s, \text{elec.}}$		-20 - 85	°C
Humidity	$RH_{s, \text{elec.}}$	Noncondensing	20 - 80	%RH
Transducerhead				
Temperature	$T_{s, \text{head}}$		-20 - 85	°C
Humidity	$RH_{s, \text{head}}$	Noncondensing	20 - 80	%RH
Mechanical dimension				
Electronics				
Width	$W_{\text{elec.}}$		482.6	mm
Height	$H_{\text{elec.}}$		88.1	mm
Depth	$D_{\text{elec.}}$		323	mm
Weight (approx.)	$m_{\text{elec.}}$		5	kg
Transducerhead				
Width	W_{head}		98	mm
Height	H_{head}		122	mm
Depth	D_{head}		57	mm
Weight (approx.)	m_{head}		1	kg
Inner hole diameter	O		25	mm
Transducer cable lenght				
Standard			2.5	m
Maximum optional lenght			30	m

Notes:

- 1: All ppm figures refer to nominal current and transducerhead programmed to maximum primary current
- 2: Specifications is subject to change without notice

Ultrastab Saturn 600U

Last update: 15.03.2007

Rack mounted programmable current transducer

Parameter	Symbol	Condition	Value	Unit
Primary current				
	I_p			
Nominal primary current			± 600	A
Programmable from			40	A
Programming steps			20	A
Polarity			Bipolar	
Voltage output				
	V_o			
Nominal voltage output	V_{on}		± 10	V
Max. output load current	$I_{o, max}$		5	mA
Max. output load capacitance	$C_{o, max}$		3	nF
Transfer ratio				
	G		60	A/V
Overload capacity				
Max. nondestructive overload	$I_{p, max}$	@ 0.1s	500	%I _{pn}
Min. overload trip value	$I_{p, trip}$		130	%I _{pn}
DC accuracy				
Offset				
Initial	V_{oo}		< 2	ppm
Drift vs. Temp.	$V_{oo, temp}$		< 0.6	ppm / K
Drift vs. Time	$V_{oo, time}$		< 1	ppm / month
Transfer ratio				
Deviation	G_d		< 50	ppm
Deviation vs. Temp.	$G_{d, temp}$		< 2	ppm / K
Deviation vs. Time	$G_{d, time}$		< 2	ppm / month
Linearity				
Deviation	X_d		< 3	ppm
Output noise				
	$V_{o, noise}$			
		0 - 10Hz	< 0.15	ppm (RMS)
		0 - 10kHz	< 6.5	ppm (RMS)
		0 - 100kHz	< 16	ppm (RMS)

Ultrastab Saturn 600U

Last update: 15.03.2007

Rack mounted programmable current transducer

Parameter	Symbol	Condition	Value	Unit
Dynamic response				
Slew rate	dI/dt	See note 3	> 50	A / μS
Delay time	t _d		< 1	μS
Bandwidth				
±3dB	f	< 5% I _{pn}	0 - 300	kHz
Busbar noise				
Measured on primary cable, one turn	U _b	DC - 100kHz	< 2	μV RMS
Busbar free zone				
Lenght	l		150	mm
Radius	r		75	mm
Operating voltages				
Max. busbar voltages	V _{b, max}		1250	VAC
Test voltages				
Busbar to GND	V _{t, b}		5000	VAC RMS
Power supply				
Supply voltage (Selectable on mains inlet)	V _{ac}	± 10%	100/110/230	VAC, 50~60Hz
Maximum power consumption	S _{max}		50	VA
Operating environment				
Electronics				
Temperature	T _{a, elec.}	Noncondensing	10 - 40	°C
Humidity	RH _{a, elec.}		20 - 80	%RH
Transducerhead				
Temperature	T _{a, head}	Noncondensing	0 - 55	°C
Humidity	RH _{a, head}		20 - 80	%RH

Ultrastab Saturn 600U

Last update: 15.03.2007

Rack mounted programmable current transducer

Parameter	Symbol	Condition	Value	Unit
Storage environment				
Electronics				
Temperature	$T_{s, \text{elec.}}$		-20 - 85	°C
Humidity	$RH_{s, \text{elec.}}$	Noncondensing	20 - 80	%RH
Transducerhead				
Temperature	$T_{s, \text{head}}$		-20 - 85	°C
Humidity	$RH_{s, \text{head}}$	Noncondensing	20 - 80	%RH
Mechanical dimension				
Electronics				
Width	$W_{\text{elec.}}$		482.6	mm
Height	$H_{\text{elec.}}$		88.1	mm
Depth	$D_{\text{elec.}}$		323	mm
Weight (approx.)	$m_{\text{elec.}}$		5	kg
Transducerhead				
Width	W_{head}		98	mm
Height	H_{head}		122	mm
Depth	D_{head}		57	mm
Weight (approx.)	m_{head}		1	kg
Inner hole diameter	O		25	mm
Transducer cable lenght				
Standard			2.5	m
Maximum optional lenght			30	m

Notes:

- 1: All ppm figures refer to nominal current and transducerhead programmed to maximum primary current
- 2: Specifications is subject to change without notice
- 3: Corresponds to 1V/uS on the voltage output with transducerhead programmed to maximum primary current

Ultrastab Saturn 2000I

Last update: 15.03.2007

Rack mounted programmable current transducer

Parameter	Symbol	Condition	Value	Unit
Primary current	I_p			
Nominal primary current			± 2000	A
Programmable from			125	A
Programming steps			125	A
Polarity			Bipolar	
Secondary current	I_s			
Nominal secondary current			± 1	A
External burden resistor	R_b			
Max.	$R_{b, \max}$		1.5	Ω
Min.	$R_{b, \min}$		0	Ω
Current transfer ratio	N		2000	
Overload capacity				
Max. nondestructive overload	$I_{p, \max}$	@ 0.1s	500	%I _{pn}
Min. overload trip value	$I_{p, \text{trip}}$		130	%I _{pn}
DC accuracy				
Offset				
Initial	I_{so}		< 2	ppm
Drift vs. Temp.	$I_{so, \text{temp}}$		< 0.1	ppm / K
Drift vs. Time	$I_{so, \text{time}}$		< 1	ppm / month
Transfer ratio				
Deviation	N_d		< 4	ppm
Deviation vs. Temp.	$N_{d, \text{temp}}$		< 0.1	ppm / K
Deviation vs. Time	$N_{d, \text{time}}$		< 1	ppm / month
Linearity				
Deviation	X_d		< 2	ppm
Deviation vs. Temp.	$X_{d, \text{temp}}$		< 0.1	

Ultrastab Saturn 2000I

Last update: 15.03.2007

Rack mounted programmable current transducer

Parameter	Symbol	Condition	Value	Unit
Output noise	$I_{s, \text{noise}}$			
		0 - 10Hz	< 0.01	ppm (RMS)
		0 - 10kHz	< 3	ppm (RMS)
		0 - 100kHz	< 5.5	ppm (RMS)
Dynamic response				
Slew rate	dI/dt	10 - 90%	> 20	A / μS
Delay time	t_d		< 1	μS
Bandwidth $\pm 3dB$	f	< 1% I_{pn}	0 - 50	kHz
Busbar noise Measured on primary cable, one turn	U_b	DC - 100kHz	< 10	μV RMS
Busbar free zone				
Lenght	l		220	mm
Radius	r		110	mm
Operating voltages Max. busbar voltages	$V_{b, \text{max}}$		2100	VAC
Test voltages Busbar to GND	$V_{t, b}$		5000	VAC RMS
Power supply				
Supply voltage (Selectable on mains inlet)	Vac	$\pm 10\%$	100/110/230	VAC, 50~60Hz
Maximum power consumption	S_{max}		50	VA

Ultrastab Saturn 2000I

Last update: 15.03.2007

Rack mounted programmable current transducer

Parameter	Symbol	Condition	Value	Unit
Operating environment				
Electronics				
Temperature	$T_{a, \text{elec.}}$		10 - 40	°C
Humidity	$RH_{a, \text{elec.}}$	Noncondensing	20 - 80	%RH
Transducerhead				
Temperature	$T_{a, \text{head}}$		0 - 55	°C
Humidity	$RH_{a, \text{head}}$	Noncondensing	20 - 80	%RH
Mechanical dimension				
Electronics				
Width	$W_{\text{elec.}}$		482.6	mm
Height	$H_{\text{elec.}}$		88.1	mm
Depth	$D_{\text{elec.}}$		323	mm
Weight (approx.)	$m_{\text{elec.}}$		5	kg
Transducerhead				
Width	W_{head}		169	mm
Height	H_{head}		200	mm
Depth	D_{head}		70	mm
Weight (approx.)	m_{head}		4.5	kg
Inner hole diameter	O		50	mm
Transducer cable lenght				
Standard			2.5	m
Maximum optional lenght			30	m

Notes:

- 1: All ppm figures refer to nominal current and transducerhead programmed to maximum primary current
- 2: Specifications is subject to change without notice

Ultrastab Saturn 2000U

Last update: 15.03.2007

Rack mounted programmable current transducer

Parameter	Symbol	Condition	Value	Unit
Primary current				
	I_p			
Nominal primary current			± 2000	A
Programmable from			125	A
Programming steps			125	A
Polarity			Bipolar	
Voltage output				
	V_o			
Nominal voltage output	V_{on}		± 10	V
Max. output load current	$I_{o, max}$		5	mA
Max. output load capacitance	$C_{o, max}$		3	nF
Transfer ratio				
	G		200	A/V
Overload capacity				
Max. nondestructive overload	$I_{p, max}$	@ 0.1s	500	% I_{pn}
Min. overload trip value	$I_{p, trip}$		130	% I_{pn}
DC accuracy				
Offset				
Initial	V_{oo}		< 2	ppm
Drift vs. Temp.	$V_{oo, temp}$		< 0.6	ppm / K
Drift vs. Time	$V_{oo, time}$		< 1	ppm / month
Transfer ratio				
Deviation	G_d		< 50	ppm
Deviation vs. Temp.	$G_{d, temp}$		< 2	ppm / K
Deviation vs. Time	$G_{d, time}$		< 2	ppm / month
Linearity				
Deviation	X_d		< 4	ppm
Output noise				
	$V_{o, noise}$			
		0 - 10Hz	< 0.15	ppm (RMS)
		0 - 10kHz	< 5.5	ppm (RMS)
		0 - 100kHz	< 16	ppm (RMS)

Ultrastab Saturn 2000U

Last update: 15.03.2007

Rack mounted programmable current transducer

Parameter	Symbol	Condition	Value	Unit
Dynamic response				
Slew rate	dI/dt	See note 3	> 20	A / μ S
Delay time	t_d		< 1	μ S
Bandwidth				
± 3 dB	f	< 1% I_{pn}	0 - 50	kHz
Busbar noise				
Measured on primary cable, one turn	U_b	DC - 100kHz	< 10	μ V RMS
Busbar free zone				
Length	l		220	mm
Radius	r		110	mm
Operating voltages				
Max. busbar voltages	$V_{b, max}$		2100	VAC
Test voltages				
Busbar to GND	$V_{t, b}$		5000	VAC RMS
Power supply				
Supply voltage (Selectable on mains inlet)	V_{ac}	$\pm 10\%$	100/110/230	VAC, 50~60Hz
Maximum power consumption	S_{max}		50	VA
Operating environment				
Electronics				
Temperature	$T_{a, elec.}$		10 - 40	$^{\circ}$ C
Humidity	$RH_{a, elec.}$	Noncondensing	20 - 80	%RH
Transducerhead				
Temperature	$T_{a, head}$		0 - 55	$^{\circ}$ C
Humidity	$RH_{a, head}$	Noncondensing	20 - 80	%RH

Ultrastab Saturn 2000U

Last update: 15.03.2007

Rack mounted programmable current transducer

Parameter	Symbol	Condition	Value	Unit
Mechanical dimension				
Electronics				
Width	$W_{elec.}$		482.6	mm
Height	$H_{elec.}$		88.1	mm
Depth	$D_{elec.}$		323	mm
Weight (approx.)	$m_{elec.}$		5	kg
Transducerhead				
Width	W_{head}		169	mm
Height	H_{head}		200	mm
Depth	D_{head}		70	mm
Weight (approx.)	m_{head}		4.5	kg
Inner hole diameter	O		50	mm
Transducer cable lenght				
Standard			2.5	m
Maximum optional lenght			30	m

Notes:

- 1: All ppm figures refer to nominal current and transducerhead programmed to maximum primary current
- 2: Specifications is subject to change without notice
- 3: Corresponds to 0.1mV/uS on the voltage output with transducerhead programmed to maximum primary current

Appendix C: Drawings

A B C D E F G H I J

1

2

3




4

5

6

7

8



Rear view




IMPORTANT!
This document contains information which is the property of Danfysik A/S, Denmark. It is submitted to you in confidence that it will not be disclosed or transmitted to others without Danfysik's authorization.

TOLERANCE: ±0.1		SURFACE TREATMENT (RoHS compliant):		MATERIAL:	
SCALE: 1:10		MACHINING:		DRAWN BY SFH	
<div>Ultrastab Saturn</div> <div>Dimensions</div>				DESIGN APP. Autodesk Inventor 9	
				PROD. APP.	
				PROJ. ENGR.	
				DWG. NO.:	
				89401	
<div><div></div><div>DANFYSIK</div></div>		CUSTOMER: Customer		PROJECT NO.:	
FILE: 89401.idw				REVISION:	
				SHEET 1 of 1	
				DATE: 28-07-2006	
				SIZE: A4	



FIRST ANGLE
PROJECTION

A B C D E F G H I J



IMPORTANT!
This document contains information which is the property of Danfysik A/S, Denmark. It is submitted to you in confidence that it will not be disclosed or transmitted to others without Danfysik's authorization.

FIRST ANGLE
PROJECTION

A B C D E F G H I J

1

2

3



4

5


6

7

8







IMPORTANT!
This document contains information which is the property of Danfysik A/S, Denmark. It is submitted to you in confidence that it will not be disclosed or transmitted to others without Danfysik's authorization.

TOLERANCE: N.A.		SURFACE TREATMENT (RoHS compliant):		MATERIAL:	
SCALE: 1:4		MACHINING:		DRAWN BY SFH	
<div>STH 2000 - DCCT</div> <div>Dimensions</div> <div>Ultrastab Saturn</div>				DESIGN APP. Autodesk Inventor 9	
				PROD. APP.	
				PROJ. ENGR.	
				DWG. NO.:	
				89403	
 DANFYSIK		CUSTOMER: Customer		PROJECT NO.:	
FILE: 89403.idw				REVISION:	
				SHEET 1 of 1	
				DATE: 28-07-2006	
				SIZE: A4	




FIRST ANGLE
PROJECTION





A B C D E F G H I J




IMPORTANT!
This document contains information which is the property of Danfysik A/S, Denmark. It is submitted to you in confidence that it will not be disclosed or transmitted to others without Danfysik's authorization.

TOLERANCE: ± 0.1	SURFACE TREATMENT (RoHS compliant):	MATERIAL:
SCALE: 1:4	MACHINING:	
STH-5000-62 Dimensions Ultrastab Saturn		DRAWN BY SFH
		DESIGN APP. Autodesk Inventor 9
		PROD. APP.
		PROJ. ENGR.
		DWG. NO.: 89417
		REVISION:
CUSTOMER: Danfysik		SHEET 1 of 1
PROJECT NO.: Ultrastab Saturn		DATE: 01-09-2006
FILE: 89417.idw		SIZE: A4

FIRST ANGLE
PROJECTION



IMPORTANT!
This document contains information which is the property of Danfysik A/S, Denmark. It is submitted to you in confidence that it will not be disclosed or transmitted to others without Danfysik's authorization.


TOLERANCE: ± 0.1	SURFACE TREATMENT (RoHS compliant):	MATERIAL:
SCALE: 1:5	MACHINING:	
STH-5000-140 Dimensions Ultrastab Saturn		DRAWN BY SFH
		DESIGN APP. Autodesk Inventor 9
		PROD. APP.
		PROJ. ENGR.
		DWG. NO.: 89416
		REVISION:
CUSTOMER: Customer		SHEET 1 of 1
PROJECT NO.: Ultrastab Saturn		DATE: 01-09-2006
FILE: 89416.idw		SIZE: A4

FIRST ANGLE
PROJECTION

A B C D E F G H I J

1

1




2

2


3

3



4

4



5

5

6

6

IMPORTANT!
This document contains information which is the property of Danfysik A/S, Denmark. It is submitted to you in confidence that it will not be disclosed or transmitted to others without Danfysik's authorization.

7

7

TOLERANCE: ±0.3		SURFACE TREATMENT (RoHS compliant):		MATERIAL:	
SCALE: 1:1		MACHINING:			
<div>Plug dimensions</div>				DRAWN BY SFH	
				DESIGN APP.	
				PROD. APP.	
				PROJ. ENGR. NAW	
				DWG. NO.: 89439	
<div><div></div><div>DANFYSIK</div></div>		CUSTOMER: Customer		PROJECT NO.:	
FILE: 89439.idw				REVISION:	
				SHEET 1 of 1	
				DATE: 03-01-2007	
				SIZE: A4	

8


8



FIRST ANGLE
PROJECTION

A B C D E F G H I J


DB25 FEMALE



All wires: 0.25mm2 Black


DWG 65-0-89260

T:\PROJETER-IGANG\SATURN\DOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89260.DSN

Programming plug			DRAWN BY. 25-01-2006 / NAW		
60 / 250 A			DESIGN APP.		
Transducerhead 600 / 2000 A			PROD APP.		
Ultrastab Saturn			PROJ. ENGR.		
			DWG.NO.:		
			89260		
	CUSTM. <OrgName>		REV.	SHEET. 1	OF 1
	FILE.		DATE: Thursday, August 17, 2006		
	ORDER NO. <nr.??>		SIZE: A4		

DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK

DB25 FEMALE



All wires: 0.25mm2 Black

DWG 65-0-89261


T:\PROJEKTER\IGANGSATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89261.DSN

Programming plug			DRAWN BY. 25-01-2005 / NAW	
80 / 250 A			DESIGN APP.	
Transducer head 600 / 2000 A			PROD APP.	
Ultrastab Saturn			PROJ. ENGR.	
			DWG.NO.:	
			89261	
CUSTM. <OrgName>		ORDER NO. <nr.?->	REV.	SHEET. 1 OF 1
FILE.			DATE. Thursday, August 17, 2006	SIZE. A4



DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK

DB25 FEMALE



All wires: 0.25mm2 Black

DWG 65-0-89262


T:\PROJETER\IGANG\SATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89262.DSN

Programming plug			DRAWN BY. 25-01-2006 / NAW	
100 / 375 A			DESIGN APP.	
Transducer head 600 / 2000 A			PROD APP.	
Ultrastab Saturn			PROJ. ENGR.	
			DWG.NO.:	
			89262	
CUSTM. <OrgName>		ORDER NO. <nr.?->	REV.	SHEET. 1 OF 1
FILE.			DATE. Thursday, August 17, 2006	SIZE. A4



DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK

DB25 FEMALE



All wires: 0.25mm2 Black

DWG 65-0-89263


T:\PROJETER\IGANG\SATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89263.DSN

Programming plug			DRAWN BY. 25-01-2006 / NAW	
120 / 375 A			DESIGN APP.	
Transducer head 600 / 2000 A			PROD APP.	
Ultrastab Saturn			PROJ. ENGR.	
			DWG.NO.:	
			89263	
CUSTM. <OrgName>		ORDER NO. <nr.??>	REV.	SHEET. 1 OF 1
FILE.			DATE. Thursday, August 17, 2006	
			SIZE. A4	



DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK

DB25 FEMALE



DWG 65-0-89264


T:\PROJETER\IGANG\SATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89264.DSN

Programming plug		DRAWN BY. 25-01-2006 / NAW	
140 / 500 A		DESIGN APP.	
Transducer head 600 / 2000 A		PROD APP.	
Ultrastab Saturn		PROJ. ENGR.	
		DWG.NO.:	
		89264	
CUSTM. <OrgName>		REV.	SHEET. 1 OF 1
FILE.		DATE. Thursday, August 17, 2006	
ORDER NO. <nr.??>		SIZE. A4	



DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK


DB25 FEMALE



All wires: 0.25mm2 Black


DWG 65-0-89265

T:\PROJETER\IGANG\SATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89265.DSN

Programming plug			DRAWN BY. 25-01-2006 / NAW	
160 / 500 A			DESIGN APP.	
Transducerhead 600 / 2000 A			PROD APP.	
Ultrastab Saturn			PROJ. ENGR.	
			DWG.NO.:	
			89265	
 DANFYSIK	CUSTM. <OrgName>		REV.	SHEET. 1 OF 1
	FILE.		DATE. Thursday, August 17, 2006	SIZE. A4

DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK

DB25 FEMALE




DWG 65-0-89266

T:\PROJETER\IGANG\SATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89266.DSN

Programming plug			DRAWN BY. 25-01-2006 / NAW	
180 / 625 A			DESIGN APP.	
Transducerhead 600 / 2000 A			PROD APP.	
Ultrastab Saturn			PROJ. ENGR.	
			DWG.NO.:	
			89266	
CUSTM. <OrgName>		ORDER NO. <nr.??>	REV.	SHEET. 1 OF 1
FILE.			DATE. Thursday, August 17, 2006	
			SIZE. A4	




DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK




DWG 65-0-89267

T:\PROJEKTER-IGANG\SATURN\DOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89267.DSN

Programming plug					DRAWN BY. 25-01-2006 / NAW		
200 / 625 A					DESIGN APP.		
Transducer head 600 / 2000 A					PROD APP.		
Ultrastab Saturn					PROJ. ENGR.		
					DWG.NO.:		
					89267		
		CUSTM. <OrgName>		ORDER NO. <nr.?>	REV.	SHEET. 1	OF 1
		FILE.				DATE. Thursday, August 17, 2006	SIZE. A4
DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK							


DB25 FEMALE



All wires: 0.25mm2 Black


DWG 65-0-89268

T:\PROJEKTER\IGANG\SATURN\IDOKUMENTATION, MIDLERTID\IG\PROGRAMMING PLUGS\PLUGS_600_2000\89268.DSN

Programming plug		DRAWN BY. 25-01-2006 / NAW	
220 / 750 A		DESIGN APP.	
Transducer head 600 / 2000 A		PROD APP.	
Ultrastab Saturn		PROJ. ENGR.	
		DWG.NO.:	
		89268	
 DANFYSIK	CUSTM. <OrgName>	REV.	SHEET. 1 OF 1
	FILE.	DATE. Thursday, August 17, 2006	
	ORDER NO. <nr.??>		
			SIZE. A4

DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK


DB25 FEMALE



All wires: 0.25mm2 Black


DWG 65-0-89269

T:\PROJEKTER\IGANGSATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89269.DSN

Programming plug			DRAWN BY. <dato sign>		
240 / 750 A			DESIGN APP.		
Transducer head 600 / 2000 A			PROD APP.		
Ultrastab Saturn			PROJ. ENGR.		
			DWG.NO.:		
			89269		
 DANFYSIK	CUSTM. <OrgName>		REV.	SHEET. 1	OF 1
	FILE.		DATE. Thursday, August 17, 2006		
	ORDER NO. <nr. ?>		SIZE. A4		

DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK


DB25 FEMALE



All wires: 0.25mm2 Black


DWG 65-0-89270

T:\PROJETER\IGANG\SATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89270.DSN

Programming plug			DRAWN BY. 25-01-2006 / NAW	
260 / 875 A			DESIGN APP.	
Transducer head 600 / 2000 A			PROD APP.	
Ultrastab Saturn			PROJ. ENGR.	
			DWG.NO.:	
			89270	
	CUSTM. <OrgName>		REV.	SHEET. 1 OF 1
	FILE.		DATE. Thursday, August 17, 2006	SIZE. A4

DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK

DB25 FEMALE




X1

All wires: 0.25mm2 Black


DWG 65-0-89271

T:\PROJEKTER\IGANGSATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89271.DSN

Programmig plug				DRAWN BY. <dato sign>			
280 / 875 A				DESIGN APP.			
Transducer head 600 / 200 A				PROD APP.			
Ultrastab Saturn				PROJ. ENGR.			
				DWG.NO.:			
				89271			
		CUSTM. <OrgName>		REV.		SHEET. 1 OF 1	
		FILE.		DATE: Thursday, August 17, 2006			
		ORDER NO. <nr.??>				SIZE: A4	

DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK

DB25 FEMALE



All wires: 0.25mm2 Black

65-0-89273


T:\PROJETER\IGANG\SATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89273.DSN

DRAWN BY. 25-01-2006 / NAW		REV.	SHEET. 1 OF 1
DESIGN APP.		DATE. Thursday, August 17, 2006	SIZE. A4
PROD APP.			
PROJ. ENGR.			
DWG.NO.:			
89273			
Programming plug			
320 / 1000 A			
Transducerhead 600 / 2000 A			
Ultrastab Saturn			
CUSTM. <OrgName>			
FILE.			
ORDER NO. <nr.?->			



DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK

DB25 FEMALE



X1

All wires: 0.25mm2 Black

65-0-89274


T:\PROJETER\IGANG\SATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89274.DSN

Programming plug			DRAWN BY. 26-01-2006 / NAW	
340 / 1125 A			DESIGN APP.	
Transducerhead 600 / 2000 A			PROD APP.	
Ultrastab Saturn			PROJ. ENGR.	
			DWG.NO.:	
			89274	
CUSTM. <OrgName>		ORDER NO. <nr.?:>	REV.	SHEET. 1 OF 1
FILE.			DATE. Thursday, August 17, 2006	
SIZE. A4				



DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK

DB25 FEMALE



All wires: 0.25mm2 Black

65-0-89275


T:\PROJEKTER-IGANGSATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89275.DSN

Programming plug			DRAWN BY. 25-01-2005 / NAW	
360 / 1125 A			DESIGN APP.	
Transducerhead 600 / 2000 A			PROD APP.	
Ultrastab Saturn			PROJ. ENGR.	
			DWG.NO.:	
			89275	
CUSTM. <OrgName>		ORDER NO. <nr.?->	REV.	SHEET. 1 OF 1
FILE.			DATE. Thursday, August 17, 2006	SIZE. A4



DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK

DB25 FEMALE




X1

All wires: 0.25mm2 Black


65-0-89276

T:\PROJETER-IGANG\SATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89276.DSN

Programming plug		DRAWN BY. 25-01-2006 / NAW	
380 / 1250 A		DESIGN APP.	
Transducerhead 600 / 2000 A		PROD APP.	
Ultrastab Saturn		PROJ. ENGR.	
		DWG.NO.:	
		89276	
 DANFYSIK	CUSTM. <OrgName> FILE.	REV.	SHEET. 1 OF 1
		DATE. Thursday, August 17, 2006 SIZE. A4	

DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK


DB25 FEMALE



All wires: 0.25mm2 Black


65-0-89277

T:\PROJETER\IGANG\SATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89277.DSN

Programming plug			DRAWN BY. 25-01-2006 / NAW	
400 / 1250 A			DESIGN APP.	
Transducerhead 600 / 2000 A			PROD APP.	
Ultrastab Saturn			PROJ. ENGR.	
			DWG.NO.:	
			89277	
 DANFYSIK		CUSTM. <OrgName>	REV.	SHEET. 1 OF 1
		FILE.	DATE. Thursday, August 17, 2006	SIZE. A4

DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK


DB25 FEMALE



All wires: 0.25mm2 Black


65-0-89278

T:\PROJEKTER\IGANGSATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89278.DSN

Programming plug				DRAWN BY. 25-01-2006 / NAW			
420 / 1375 A				DESIGN APP.			
Transducerhead 600 / 2000 A				PROD APP.			
Ultrastab Saturn				PROJ. ENGR.			
				DWG.NO.:			
				89278			
		CUSTM. <OrgName>		REV.		SHEET. 1 OF 1	
		FILE.		DATE: Thursday, August 17, 2006			
		ORDER NO. <nr.??>		SIZE: A4			

DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK


DB25 FEMALE



All wires: 0.25mm2 Black


65-0-89279

T:\PROJETER\IGANG\SATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89279.DSN

Programming plug			DRAWN BY. 25-01-2006 / NAW	
440 / 1375 A			DESIGN APP.	
Transducerhead 600 / 2000 A			PROD APP.	
Ultrastab Saturn			PROJ. ENGR.	
			DWG.NO.:	
			89279	
 DANFYSIK	CUSTM. <OrgName>		REV.	SHEET. 1 OF 1
	FILE.		DATE. Thursday, August 17, 2006	SIZE. A4

DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK

DB25 FEMALE



All wires: 0.25mm2 Black

65-0-89280


T:\PROJETER\IGANG\SATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89280.DSN

Programming plug			DRAWN BY. 25-01-2006 / NAW	
460 / 1500 A			DESIGN APP.	
Transducerhead 600 / 2000 A			PROD APP.	
Ultrastab Saturn			PROJ. ENGR.	
			DWG.NO.:	
			89280	
CUSTM. <OrgName>		ORDER NO. <nr.?->	REV.	SHEET. 1 OF 1
FILE.			DATE. Thursday, August 17, 2006	SIZE. A4



DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK

DB25 FEMALE



All wires: 0.25mm2 Black

65-0-89281


T:\PROJEKTER\IGANGSATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89281.DSN

Programming plug			DRAWN BY. 25-01-2006 / NAW	
480 / 1500 A			DESIGN APP.	
Transducerhead 600 / 2000 A			PROD APP.	
Ultrastab Saturn			PROJ. ENGR.	
			DWG.NO.:	
			89281	
CUSTM. <OrgName>		ORDER NO. <nr.??>	REV.	SHEET. 1 OF 1
FILE.			DATE. Thursday, August 17, 2006	
			SIZE. A4	



DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK

DB25 FEMALE



All wires: 0.25mm2 Black

65-0-89282


T:\PROJETER-IGANG\SATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89282.DSN

Programming plug			DRAWN BY. 25-01-2006 / NAW	
500 / 1625 A			DESIGN APP.	
Transducerhead 600 / 2000 A			PROD APP.	
Ultrastab Saturn			PROJ. ENGR.	
			DWG.NO.:	
			89282	
CUSTM. <OrgName>		ORDER NO. <nr.??>	REV. <RevCode>	1 OF 1
FILE.			DATE. Thursday, August 17, 2006	SIZE. A4



DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK

DB25 FEMALE



All wires: 0.25mm2 Black


65-0-89283

T:\PROJETER-IGANG\SATURN\DOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89283.DSN

Programming plug		DRAWN BY. 25-01-2006 / NAW	
520 / 1625 A		DESIGN APP.	
Transducerhead 600 /2000 A		PROD APP.	
Ultrastab Saturn		PROJ. ENGR.	
		DWG.NO.:	
89283			
CUSTM. <OrgName>		REV.	SHEET. 1 OF 1
FILE.		DATE. Thursday, August 17, 2006	
ORDER NO. <nr.?->		SIZE. A4	



DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK




All wires: 0.25mm2 Black

65-0-89284

T:\PROJEKTER-IGANG\SATURN\DOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89284.DSN

<div>Programming plug</div> <div>540 / 1750 A</div> <div>Transducerhead 600 / 2000 A</div> <div>Ultrastab Saturn</div>	DRAWN BY. 22-01-2006					
	DESIGN APP.					
	PROD APP.					
	PROJ. ENGR.					
	DWG.NO.:					
	89284					
<div><div><div></div><div></div></div><div>DANFYSIK</div></div>	CUSTM. <OrgName> FILE.	ORDER NO. <n.r.?>	REV.	SHEET. 1 OF 1	DATE. Thursday, August 17, 2006	SIZE: A4

DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK




65-0-89285

T:\PROJEKTER-IGANG\SATURN\DOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89285.DSN

Programming plug					DRAWN BY. 25-01-2006 / NAW	
560 / 1750 A					DESIGN APP.	
Transducerhead 600 / 2000 A					PROD APP.	
Ultrastab Saturn					PROJ. ENGR.	
					DWG.NO.:	
					89285	
CUSTM. <OrgName>			ORDER NO. <nr.?>	REV.	SHEET. 1	OF 1
FILE.			DATE. Thursday, August 17, 2006		SIZE: A4	

DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK


DB25 FEMALE



All wires: 0.25mm2 Black


65-0-89286

T:\PROJETER-IGANG\SATURN\DOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89286.DSN

Programming plug			DRAWN BY. <dato sign>		
580 / 1875 A			DESIGN APP.		
Transducerhead 600 / 2000 A			PROD APP.		
Ultrastab Saturn			PROJ. ENGR.		
			DWG.NO.:		
			89286		
	CUSTM. <OrgName>		REV.	SHEET. 1	OF 1
	FILE.		DATE: Thursday, August 17, 2006		
	ORDER NO. <nr.??>		SIZE: A4		

DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK


DB25 FEMALE



All wires: 0.25mm2 Black


65-0-89287

T:\PROJEKTER\IGANGSATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89287.DSN

Programming plug				DRAWN BY. 25-01-2006 / NAW			
600 / 1875 A				DESIGN APP.			
Transducerhead 600 / 2000 A				PROD APP.			
Ultrastab Saturn				PROJ. ENGR.			
				DWG.NO.:			
				89287			
 DANFYSIK		CUSTM. <OrgName>		REV.		SHEET. 1 OF 1	
		FILE.				DATE: Thursday, August 17, 2006	
		ORDER NO. <nr.??>				SIZE: A4	

DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK


DB25 FEMALE




All wires: 0.25mm2 Black

65-0-89288

T:\PROJETER-IGANG\SATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_600_2000\89288.DSN

Programming plug			DRAWN BY. 25-01-2006 / NAW	
620 / 2000 A			DESIGN APP.	
Transducerhead 600 / 2000 a			PROD APP.	
Ultrastab Saturn			PROJ. ENGR.	
			DWG.NO.:	
			89288	
 DANFYSIK	CUSTM. <OrgName>	ORDER NO. <nr.?>	REV.	SHEET. 1 OF 1
	FILE.		DATE. Thursday, August 17, 2006	SIZE. A4


DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK




All wires: 0.25mm2 Black

65-0-89289

T:\PROJEKTER-IGANG\SATURN\DOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_5000\89289.DSN

Programming plug 2500 A Transducerhead 5000 A Ultrastab Saturn	DRAWN BY. 26-01-2006 / NAW		
	DESIGN APP.		
	PROD APP.		
	PROJ. ENGR.		
	DWG.NO.:		
	89289		
	CUSTM. <OrgName>	ORDER NO. <nr. ?>	REV. <RevCode> SHEET. 1 OF 1
	FILE.		DATE. Thursday, August 17, 2006 SIZE: A4


DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK



All wires: 0.25mm2 Black


65-0-89290

T:\PROJEKTER-IGANG\SATURN\DOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_5000\89290.DSN

Programming plug 2750A Transducerhead 5000A Ultrastab Saturn	DRAWN BY. 26-01-2006				
	DESIGN APP.				
	PROD APP.				
	PROJ. ENGR.				
	DWG.NO.:				
89290					
	CUSTM. <OrgName>	ORDER NO. <nr.?>	REV.	SHEET. 1	OF 1
	FILE.	DATE. Thursday, August 17, 2006			SIZE: A4

DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK

DB25 FEMALE



All wires: 0.25mm2 Black

X1

65-0-89291


T:\PROJEKTER\IGANGSATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\5000\89291.DSN

Programming plug			DRAWN BY. 26-01-2006 / NAW	
3000 A			DESIGN APP.	
Transducerhead 5000 A			PROD APP.	
Ultrastab Saturn			PROJ. ENGR.	
			DWG.NO.:	
			89291	
CUSTM. <OrgName>		ORDER NO. <nr.?->	REV.	SHEET. 1 OF 1
FILE.			DATE. Thursday, August 17, 2006	
			SIZE: A4	



DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK

DB25 FEMALE



All wires: 0.25mm2 Black

X1

65-0-89292


T:\PROJEKTER\IGANGSATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_5000\89292.DSN

Programming plug			DRAWN BY. 26-01-2006 / NAW		
3250A			DESIGN APP.		
Transducerhead 5000A			PROD APP.		
Ultrastab Saturn			PROJ. ENGR.		
			DWG.NO.:		
			89292		
CUSTM. <OrgName>		ORDER NO. <nr. ?>	REV.	SHEET. 1	OF 1
FILE.			DATE. Thursday, August 17, 2006		SIZE. A4



DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK

DB25 FEMALE



All wires: 0.25mm2 Black


65-0-89293

T:\PROJEKTER\IGANGSATURN\IDOKUMENTATION, MIDLERTID\IG\PROGRAMMING PLUGS\PLUGS_5000\89293.DSN

Programming plug			DRAWN BY. 26-01-2006 / NAW	
3500 A			DESIGN APP.	
Transducerhead 5000 A			PROD APP.	
Ultrastab Saturn			PROJ. ENGR.	
			DWG.NO.:	
			89293	
CUSTM. <OrgName>		ORDER NO. <nr.??>	REV.	SHEET. 1 OF 1
FILE.			DATE. Thursday, August 17, 2006	SIZE. A4





DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK



65-0-89294

T:\PROJEKTER-IGANG\SATURN\DOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_5000\89294.DSN


Programming plug 3750A Transducerhead 5000A Ultrastab Saturn	DRAWN BY. 26-01-2006 / NAW				
	DESIGN APP.				
	PROD APP.				
	PROJ. ENGR.				
	DWG.NO.:				
89294					
 DANFYSIK	CUSTM. <OrgName>	ORDER NO. <nr.?>	REV.	SHEET. 1	OF 1
	FILE.		DATE. Thursday, August 17, 2006		SIZE: A4
DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 01 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK					



All wires: 0.25mm2 Black


65-0-89295

T:\PROJEKTER-IGANG\SATURN\DOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_5000\89295.DSN

Programming plug 4000 A Transducerhead 5000 A Ultrastab Saturn	DRAWN BY. 26-01-2006 / NAW				
	DESIGN APP.				
	PROD APP.				
	PROJ. ENGR.				
	DWG.NO.:				
89295					
	CUSTM. <OrgName>	ORDER NO. <nr.?>	REV.	SHEET. 1	OF 1
	FILE.		DATE. Thursday, August 17, 2006		
	SIZE: A4				

DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK


DB25 FEMALE




All wires: 0.25mm2 Black

65-0-89296

T:\PROJEKTER\IGANG\SATURN\IDOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_5000\89296.DSN

Programming plug		DRAWN BY. 26-01-2006 / NAW	
4250A		DESIGN APP.	
Transducerhead 5000A		PROD APP.	
Ultrastab Saturn		PROJ. ENGR.	
		DWG.NO.:	
		89296	
 DANFYSIK	CUSTM. <OrgName>		REV.
	FILE.		SHEET. 1 OF 1
DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK		DATE. Thursday, August 17, 2006	
		SIZE: A4	




All wires: 0.25mm2 Black

65-0-89297

T:\PROJEKTER-IGANG\SATURN\DOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS 5000\89297.DSN

<div>Programming plug</div> <div>4500 A</div> <div>Transducerhead 5000 A</div> <div>Ultrastab Saturn</div>	DRAWN BY. 26-01-2006 / NAW				
	DESIGN APP.				
	PROD APP.				
	PROJ. ENGR.				
	DWG.NO.:				
	89297				
<div><div></div><div>DANFYSIK</div></div>	CUSTM. <OrgName>	ORDER NO. <nr.?>	REV.	SHEET. 1	OF 1
	FILE:			DATE. Thursday, August 17, 2006	SIZE: A4

DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK




All wires: 0.25mm2 Black

65-0-89298

T:\PROJEKTER-IGANG\SATURN\DOKUMENTATION. MIDLERTIDIG\PROGRAMMING PLUGS 5000\89298.DSN


<div>Programming plug</div> <div>4750A</div> <div>Transducerhead 5000A</div> <div>Ultrastab Saturn</div>	DRAWN BY. 26-01-2006 / NAW				
	DESIGN APP.				
	PROD APP.				
	PROJ. ENGR.				
	DWG.NO.:				
	89298				
<div><div></div><div>DANFYSIK</div></div>	CUSTOM. <OrgName>	ORDER NO. <nr.?>	REV.	SHEET. 1	OF 1
	FILE.			DATE. Thursday, August 17, 2006	SIZE: A4


DK-4040 JYLLINGE DENMARK TELEPHONE: +45 46 79 00 00 TELEFAX: +45 46 79 00 01 E-MAIL: DANFYSIK@DANFYSIK.DK



65-0-89299

T:\PROJEKTER-IGANG\SATURN\DOKUMENTATION, MIDLERTIDIG\PROGRAMMING PLUGS\PLUGS_5000\89299.DSN

	CUSTM. <OrgName>	ORDER NO. <nr.?>	REV.	SHEET. 1	OF 1
	FILE:				SIZE: A4
	DATE: Thursday, August 17, 2006				
DRAWN BY. 26-01-2006 / NAW DESIGN APP. PROD APP. PROJ. ENGR. DWG.NO.: <div style="text-align: right;">89299</div>					

 DANFYSIK	CUSTM. <OrigName>		ORDER NO. <nr. ?>	REV.	SHEET. 1	OF 1
	FILE.		DATE. Thursday, August 17, 2006			


PROPRIETARY
THIS DRAWING CONTAINS CONFIDENTIAL INFORMATION
PROPRIETARY TO GMW INC. IT MUST NOT BE
REPRODUCED OR DISCLOSED TO OTHERS OR USED IN ANY
OTHER MANNER, IN WHOLE OR IN PART EXCEPT AS AUTHORIZED
IN WRITING BY GMW INC.

LABEL

GMW Associates
Cable Assembly
P/N: 16900451
600A RMS, 1,000V
www.gmw.com



SECTION A-A



1 PLACE RED SHRINK TUBE UNDER CLEAR

NOTES:

1. INSULATION VOLTAGE RATING:
1kV
2. WIRE SPECIFICATIONS:
COBRA WIRE P/N: A2104B
TYPES / APPROVALS:
UL Listed
NEC types: MTW & THW
UL AWM Styles: 1232, 1283, 1338, 10070, 10269
UL Approved for 1000V
CSA Certified
TEW A/B FT-1
"Ct" Approved

ITEM	QTY	PART NUMBER	DESCRIPTION	NOTE
6	1		PART NUMBER LABEL	
5	1	FIT221-1-RED	SHRINK TUBING, 1", RED, CUT 12mm	
4	1	FIT221-1-BLK	SHRINK TUBING, 1", CLEAR, CUT 80mm	
3	2	FIT321-1	SHRINK TUBING, 1", ADHESIVE, CUT 76mm	
2	2	12900250	COPPER LUG, MODIFIED	
1	3	A2002B	COBRA X-FLEX WIRE, 2GA, CUT 660mm	

PARTS LIST		DO NOT SCALE		FROM DRAWING	
DRAWN	DATE	DIMENSIONS & TOLERANCES		(UNLESS OTHERWISE SPECIFIED)	
M. Duffy	20 Mar, 07	LINEAR		INCHES/	
CHECK	DATE	X.XXX		mm	
M. Duffy	20 Mar, 07	X.XX		±.01	
ENGINEERING	DATE	X		±.03	
M. Duffy	20 Mar, 07	DEC.		±.06	
		FINISH		±.5	
		THIRD ANGLE PROJECTION		1.6	
NEXT ASSY	SYSTEM	SCALE		NTS	
SOFTWARE	AUTOCAD 2000	WT		kg	
		SHEET		1 OF 1	

GMW

955 Industrial Rd, San Carlos, CA 94070
Tel: (650)802-8292. Fax: (650)802-8298.

PRIMARY CURRENT

CABLE - 866/867

DRAWING NO.

A2 16900451





REV

A

PROPRIETARY
THIS DRAWING CONTAINS CONFIDENTIAL
INFORMATION PROPRIETARY TO GMW INC. IT IS NOT
TO BE REPRODUCED OR TRANSMITTED IN ANY FORM
OR BY ANY MEANS, ELECTRONIC OR MECHANICAL,
INCLUDING PHOTOCOPYING, RECORDING, OR BY
ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM,
WITHOUT THE WRITTEN PERMISSION OF GMW INC.
EXCEPT AS AUTHORIZED IN WRITING BY GMW INC.

REVISION HISTORY		
ZONE	REV	DESCRIPTION
1	1	Release

DATE	APPROVED
4/13/2007	Michael E. Duffy




Max. Current / Voltage Rating: 1,500A RMS, 1,000V

Note: Cable lug positions shown are approximate, they may be relocated as required by system installation.

COBRA WIRE P/N: A2104B
TYPES / APPROVALS:
UL Listed
NEC types: MTW & THW
UL AWM Styles: 1232, 1284, 1338, 10070, 10269
UL Approved for 1,000V

CSA Certified
TEW A/B FT-1
"CT" Approved

DRAWN M. Duffy	DATE 13 April, 2007	DO NOT SCALE FROM DRAWING UNLESS OTHERWISE SPECIFIED	GMW Associates			
			955 Industrial Road, San Carlos, CA 94070 Tel: (650) 802-8292 Fax: (650) 802-8298			
CHECK M. Duffy	DATE 13 April, 2007	TOLERANCES FRACTIONS DECIMALS ANGLES	TITLE Bus Bar Kit with Danfysik			
			SAT2000 Transducer Head			
DESIGNED BY M. Duffy	DATE 13 April, 2007	SHEET: 1 OF 1	DRAWING NO. A2 11908-0011-1			
			THIRD ANGLE PROJECTION			
						
			kg	WT.: "	SHEET: 1	OF: 1

